

Installation instructions for aeroplus 5 service software

Hardware requirements:

- PC with Windows 2000 / XP / Vista / 7
- USB interface
- Printer

Step-by-Step instruction for Windows XP

1. Download and decompress setup file aeroplus5_x_x_x_x.zip.
(x_x_x_x represents the actual version)
2. Connect the aeroplus 5 to the USB interface of your PC and on the concentrator.
3. Windows detects the new hardware and automatically installs the necessary drivers.
If you are asked to locate the drivers, point to the folder CDM20812 in the destination folder.
4. Install the aeroplus 5 service software by starting setup.exe in the destination folder.
5. Start aeroplus 5 after successful installation in the start menu.
6. Enter the registration code.
7. The installation process is finished. The service software establishes a connection to the aeroplus 5.